

Willmar Fabrication LLC

2400 19th Ave SW Willmar, MN 56201

Phone: 888-SMARTBOX (opt. 1)

888-762-7826 (opt. 1) Fax: 320-235-0333

SMARTBOX® MOUNTING BRACKET INSTALLATION INSTRUCTIONS AGCOTM White Planters® 9000 Series - Rear Mount

Bracket Part No. SB021532 - for use with 2 bushel seed boxes

Always use and follow planter manufacturers owner's manual recommended safety guidelines.

Prior to installation, unfold planter and leave the planter row units in the raised position.

See the attached Drawing No. SB021532 and the AMVAC SmartBox System Parts and Operator's Manual for additional installation information.



A. Start by attaching the Plate Angle, RH & LH (*item no.* 13 and 14) to the seed box's front cast iron mounting location using the bolt, washer, and nut (*item no.* 4, 9 and 16) provided.

As shown, the thick washer serves as a spacer.



Page 1 of 3

WF-2014-76 Rev 1 12/24/2013

B. Remove the row unit's closing wheel assembly pivot bolt on one side of the planter. Using the same bolt install the Weldment, Tube Brace (*item no. 15*).

Repeat this process on the opposite side of the row unit.



C. Fit the Plate, SB, Base (*item no. 11*) over the left and right Angle Plates and Tube Braces. Align the front two (2) Base Plate holes with the rearward two (2) bolt holes in the Angle Plates. The Tube Braces will be aligned with the center holes of the left and right Angle Plates. Fasten using bolts and locknuts (*item no. 3 and 7*).

NOTE: The third set of holes on the rear of the Base Plate will not be used.



Refer to the AMVAC SmartBox System Parts and Operator's Manual regarding the installation of the remainder of the system.

